

ISTRUCTIONS FOR SHUT-OFF ASSEMBLING

CUT THE MYLAR NEAR THE RIBS

REMOVE THE PIVOT OF THE COMMAND

REMOVE THE PENNY



FILL THE SPACE DESTINATED FOR ROTATION OF COMMAND

MAKE 2 HOLES OF 3 MM ON CENTRAL RIB USING AS REFERENCE THE HOLES ON THE SHUT-OFF

WARNING: PUT THE SHUT-OFF NEAR THE LEADING EDGE



FIX THE SHUT-OFF ON CENTRAL RIB

REINSTALL THE PENNY



TURN THE COMMAND OF 180°

ASSEMBLE THE COMMAND AND SPRING

TEST THE SYSTEM WITH A SILICON TUBE



ASSEMBLE ON THE MODEL A WOODEN SUPPORT WITH HOLES FOR FUEL TUBE AND BLOCK



COVER THE MODEL

MAKE A CUT IN THE LOWER PART OF THE MODEL FOR
THE EXIT OF COMMAND

